

ALL IN ONE **TQC Sheen Washability Tester** Get the best experience!

Designed to assess the performance of cleaning agents, the washability tester mimics manual handdish & hard-surface cleaning movements in a standardized way. The device is fully functional in combination with ready-to-use CFT tiles.




The Scrub Abrasion and Washability Tester is used to test cleaning, the resistance of paint, varnish or coatings to scratching, wearing, and colour loss due to wet or dry abrasion, by simulating everyday wear from cleaning actions or general use.

Weights can be added to the 4 scrub heads to give a weight loading/pressure between 300g and 1000g. This machine is clearly an replacement and improvement over the 'old' Sheen 903PG.

The Scrub Abrasion and Washability Tester is driven by a micro-step controlled electromotor which allows precise and steady speed and sinuswave form control. Operation is intuitive by means of a jog-dial switch and a multi-lingual operating menu on a large illuminated display.

Operating is very easy with the Triple i operating interface. This unique system guides the operator through the interface of TQC Sheen lab-machines. At each step of the multilingual operating menu the interface detects which buttons are active and indicates these by means of an illuminated red centre. This results in a very intuitive operating system which is enhanced with information on the machine's display.





The combination of the TQC Sheen Washability Tester and ready to use CFT testmaterials allows you to test the effects of liquid handdish & Hard Surface cleaning detergents in a standardized way. The TQC Sheen Washability tester mimics the cleaning movements without any operator dependance. By adding weight you can even mimic the manual pressure.

For our Handdish method we use a TQC Sheen Washability Tester, with the following features:

- Four scrubbing heads.
- Possibility to add weights for extra pressure.
- Multiple speed strokes.
- ٠ Pre-settings for industrial standards or your own
- Internal standard. •
- Ability to fit 2 CFT Dishwash Monitors simultaneously.

The TQC Sheen Washability Tester

- Preset range option
- Easy intuitive operating interface with Triple iControl (Intelligent Illumination Interface)
- Full color display
- Easy to update software
- Manual movement
- Compatible with a large range of accessories

The CFT setup TQC Sheen Washability Tester includes:

- 24V adapter + Power Cable
- 2x CFT Clamps
- 2x CFT inlays
- 4x Holders
- 2x trays
- 3x4 weights (4x60g, 4x100g, 4x300g)
- 20x CFT sponges
- 2x Fluid containers
- Tubing
- Pumping system
- Manual

CFT Ready-to-use dishwash tiles

This method is for Handdish & Hard surface Cleaning testing with ready-to-us tiles. CFT offers a wide range of ready to used tiles.

A selection of our ready-to-use tiles:

CFT- Testmaterials for hard surface cleaning tests							Recommended CFT-TQC Settings			
Description	Melamine	Ceramic	Glass	Stainless	Technical	Plastic	Cycles	Speed cycles /	Length in	Application
Description				steel	porcelain			min	mm	Method
Lasagne Bolognese	DM-01				DT-01		15	20	200	ABS
Shepherd's pie, baked	DM-03				DT-03		80	20	200	ABS
Carbonara sauce	DM-04		DG-04	DS-04	DT-04		15	20	200	SOAK
Cheese, baked	DM-06				DT-06	DP-06	100	20	200	ABS
Crème brulée	DM-10		DG-10		DT-10	DP-10	2	20	200	ABS
Egg Yolk	DM-21		DG-21	DS-21	DT-21		25	20	200	ABS
Boiled egg yolk (IKW)	DM-25				DT-25		20	20	200	ABS
Highly discriminative soap scum		DC-30 (BC)	DG-30	DS-30			2	40	200	SUB
Egg Yolk with Milk	DM-31		DG-31	DS-31	DT-31	DP-31	25	20	200	ABS
Egg yolk with milk, double soil load	DM-32		DG-32	DS-32	DT-32	DP-32	25	20	200	ABS
All-purpose cleaner soil (IKW)	DM-40			DS-40	DT-40		10	20	200	AC
Corn Oil				DS-50			5	20	200	AS
Oatmeal	DM-53						40	20	200	ABS
Oatmeal, coloured with chocolate	DM-54				DT-54	DP-54	5	20	200	ABS
Greasy soil (IKW)				DS-55	DT-55		5	20	200	AS
Calcium stearate (IKW)		DC-57					25	40	200	AS
Corn Starch	DM-76		DG-76	DS-76	DT-76		25	20	200	ABS
Mixed (corn/rice) starch, coloured	DM-77		DG-77	DS-77	DT-77		15	20	200	SOAK
Discriminative hydrophobic windscreen soil			DG-85				1	20	200	AS
Minced meat	DM-91				DT-91		100	20	200	ABS
All-purpose cleaner soil (IKW)	DM-178			DS-178	DT-178		10	20	200	ABS

*BC= black ceramic

*IKW = based on IKW protocol

Application Methods:

ABS Absorption of detergent in sponge
AC Applying detergent on cloth
AS Applying detergent on substrate

SOAK Soak tile in detergent solution

CFT offers many more ready-to-use tiles. For more information about the CFT tiles, please do not hesitate to contact us.

TECHNICAL DETAILS

Technical Data

Traverse speed: 1 - 60 cycles per minute Traverse speed accuracy: + / - 1% of set speed Stroke length: 20 - 300 mm / 0.39 - 11.81 in Stroke length accuracy: + / - 0.01 mm Pump flow rate: 0.0 - 3.0 ml per minute / 0.0 - 0.79 GPH Max. panel width: 70 mm / 2.76 in Max. panel length: 350 mm / 13.78 in Max. panel height: 35 mm / 1.38 in

Dimensions and Weight

Depth: 490 mm / 19.3 in Depth with pumps: 530 mm / 20.87 in Width: 640 mm / 25.2 in Height: 235 mm / 9.24 in Mass: 30 - 35 kg / 66.14 - 77.16 lbs (depending on model)



Basic Unit

Power Supply: 24 VDC / 100 - 240 V / 50 - 60 Hz Power consumption: max. 90 Watt Display: 480 x 272 pixel TFT display Control: 5-key navigation switch (Mouse Keyboard optional) Menu languages: English, Spanish, Chinese, Polish, German, French, Italian, Japanese, Russian, Turkish

ALL IN ONE TQC Sheen Washability Tester

Get the new experience!

ACCESSOIRES

A variety of tests are possible, with just small modifications to make the device suitable for other tests. This modular system significantly decreases the costs for laboratories to comply to many standards.

Some of the most used accessoires:

